



# CONDUCTIVITY CALIBRATOR

Model No. : CAL-500



**Conductivity Calibrator (Model : CAL-500) comes from POLMON ranges of Calibrators. The calibrator is designed to make calibrations convenient, quick and accurate.**

### *Features:*

- 1) Fixed precision resistors to eliminate drift.
- 2) 6 selectable Calibration Ranges.
- 3) Quick plug in for BNC & Screw terminal equipments.
- 4) ETDC certification. (Optional)

### *Specifications:*

- 1) Conductivity Ranges : 100ms, 10ms, 1ms, 100µs, 10µs, 1µs
- 2) Resistivity Ranges : 10Ω, 100Ω, 1K, 10K, 100K, 1M
- 3) Accuracy : 0.1% of the selected range
- 4) Operating Temp. : + 20°C to 70°C
- 5) Selection : Manual
- 6) termination : BNC Clips
- 5) Dimensions : 95 X 48 X 38mm
- 6) Weight : 0.135Kg.
- 7) Enclosure : ABS Plastic.

*For Further Information Contact:*

**POLMON INSTRUMENTS PVT.LTD**

(AN ISO 9001: 2000 Certified Company)

“POLMON HOUSE” Nizampet Road, Kukatpally, Hyderabad – 500 072

Ph No: 040-23053046, 23057308, 23055970, 23057642

Customer Care: 040-23892920 Fax: 040 – 23055425

e-mail: [polmon@polmon.com](mailto:polmon@polmon.com) URL: [www.polmon.com](http://www.polmon.com)